

Air brake tube, hose & fittings

Brass Reusable Fittings - Eclipse/Synflex (4245, 4247 & 3270 tubing)



Q-Cab
45° connection
to male pipe

Part #	Hose size	Thread
217-35004-03	-4	1/8 - 27

Part #	Hose size	Thread
217-38404-03	-4	1/4 - 18
217-38604-03	-4	3/8 - 18
217-38206-03	-6	1/8 - 27
217-35006-03	-6	1/4 - 18
217-38606-03	-6	3/8 - 18
217-38408-03	-8	1/4 - 18
217-35008-03	-8	3/8 - 18
217-38808-03	-8	1/2 - 14
217-38610-03	-10	3/8 - 18
217-35010-03	-10	1/2 - 14



Q-Cab
90° connection
to male pipe

Part #	Hose size	Thread
217-40004-03	-4	1/8 - 27
217-43404-03	-4	1/4 - 18

Part #	Hose size	Thread
217-43604-03	-4	3/8 - 18
217-43206-03	-6	1/8 - 27
217-40006-03	-6	1/4 - 18
217-43606-03	-6	3/8 - 18
217-43408-03	-8	1/4 - 18
217-40008-03	-8	3/8 - 18
217-43808-03	-8	1/2 - 14
217-43610-03	-10	3/8 - 18
217-40010-03	-10	1/2 - 14



Q-Cab
female connector

Part #	Hose size	Thread
1866x4	-4	1/8
1866x4x4	-4	1/4

Part #	Hose size	Thread
1866x6x2	-4	1/8
1866x6x2	-6	1/4
1866x6x6	-6	3/8
1866x8x4	-8	1/4
1866x8x4	-8	3/8
1866x8x8	-8	1/2



Q-Cab
male connector

Part #	Hose size	Thread
1868x2.5x1	-2	1/16
1868x2.5	-2	1/8
1868x3	-3	1/8
1868x4	-4	1/8

Part #	Hose size	Thread
1868x4x4	-4	1/4
1868x4x6	-4	3/8
1868x6x2	-6	1/8
1868x6	-6	1/4
1868x6x6	-6	3/8
1868x6x8	-6	1/2
1868x8x4	-8	1/4
1868x8	-8	3/8
1868x8x8	-8	1/2
1868x10x6	-8	3/8
1868x10	-10	1/2
1868x12	-12	1/2



Q-Cab
90 elbow

Part #	Hose size	Thread
1869x2.5x1	-2	1/16
1869x2.5	-2	1/8
1869x3	-3	1/8
1869x3x4	-3	1/4

Part #	Hose size	Thread
1869x4	-4	1/8
1869x4x4	-4	1/4
1869x4x6	-4	1/8
1869x6x2	-6	1/4
1869x6	-6	3/8
1869x6x6	-6	1/8
1869x6x8	-6	1/4
1869x8x4	-8	3/8
1869x8	-8	1/2
1869x8x8	-8	1/4
1869x10x6	-10	3/8
1869x10	-10	1/2



Q-Cab
union tee

Part #	Hose size	Thread
1864x4	-4	-
1864x6	-6	-
1864x8	-8	-



Q-Cab
encapsulated
cartridge

Part #	Hose size	Thread
1861x2.5	-2	-
1861x3	-3	-
1861x4	-4	-
1861x6	-6	-
1861x8	-8	-
1861x10	-10	-
1861x12	-12	-

WARNING: California Proposition 65, see pg. 201.